Manualslib.com - The Global Manuals Library

JVC AV-27F802 TV USER MANUAL

Quick Links

S P E C I F I C a T I O N

Table of Contents

important safeguards

important safety precautions

Table of Contents

Connections Checklist

Panel Diagrams

Cable and VCR Connections

Connecting to a DVD Player

Connecting to an External Amplifier

Connecting to JVC AV Compu Link

Connecting to a Camcorder

Remote Control

Power

Adjusting Volume

Changing Channels

12 Remote Programming

DVD Codes

Using the Menu

Channel Summary 1

V-CHIP

16 Plug In Menu

I n t ro d u c t i o

L a n g u a g

Auto Tuner Setup

Set Clock

F i n i s
18 Channel Summary
V- C h i
viewing guidelines
Set Lock Code
Picture Settings 23
Tint
Color
Picture
Bright
Detail
Noise Muting
Set Video Status
24 Sound Settings
Bass
Treble
Balance
MTS (Multi-channel TV Sound)
Some Sound Advice
General Items
On/Off Timer
TV Speaker
Audio Out
V4 Component-In
Closed Caption
M e n
Exit/PIP Off

Display
Video Status
Sleep Timer
Hyper Surround
Muting
Number Buttons (10 Key Pad)
Return
I n p u
VCR Buttons
DVD Buttons
TV/CATV Switch
VCR/DVD Switch
L i g h
PIP (Picture-In-Picture)
O n / M o v
F re e z
S w a
Channel
S o u rc
OURCE
Troubleshooting
32 Limited Warranty
Authorized Service Centers 33
N o t e
S p e c i f i c a t i o n
Other ManualsLib Projects

JVC®

I'Art™

COLOR TELEVISION USER'S GUIDE

For model:
AV-27F802

Illustration of AV-27F802 and RM-C301G

IMPORTANT NOTE TO THE CUSTOMER

In the space below, enter the serial number of your television (located at the rear of the television cabinet). Staple your sales receipt or invoice to the inside cover of this guide. Keep this user's guide in a convenient place for future reference. Keep the carton and original packaging for future use.

_____

Serial Number

IMPORTANT SAFETY PRECAUTIONS

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: To reduce the risk of electric shock.
Do not remove cover (or back).
No user serviceable parts inside.
Refer servicing to qualified service personnel.

The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING: TO PREVENT FIRE OR SHOCK HAZARDS, DO NOT EXPOSE THIS TV SET TO RAIN OR MOISTURE.

CAUTION: TO INSURE PERSONAL SAFETY, OBSERVE THE FOLLOWING RULES REGARDING THE USE OF THIS UNIT.

1. Operate only from the power source specified on the unit.
2. Avoid damaging the AC plug and power cord.
3. Avoid Improper installation and never position the unit where good ventilation is unattainable.
4. Do not allow objects or liquid into the cabinet openings.
5. In the event of trouble, unplug the unit and call a service technician. Do not attempt to repair it yourself or remove the rear cover.

Changes or modifications not approved by JVC could void the warranty.

* When you don't use this TV set for a long period of time, be sure to disconnect both the power plug from the AC outlet and antenna for your safety.

* To prevent electric shock do not use this polarized plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

IMPORTANT SAFEGUARDS

CAUTION:

Please read and retain for your safety.
Electrical energy can perform many useful functions. This TV set has been engineered and manufactured to assure your personal safety. But *improper use can result in potential electrical shock or fire hazards.* In order not to defeat the safeguards incorporated in this TV set, observe the following basic rules for its installation, use and servicing.
And also follow all warnings and instructions marked on your TV set.

INSTALLATION

1 Your TV set is equipped with a polarized AC line plug (one blade of the plug is wider than the other).

(POLARIZED-TYPE)



This safety feature allows the plug to fit into the power outlet only one way. Should you be unable to insert the plug fully into the outlet, try reversing the plug.
Should it still fail to fit, contact your electrician.

2 Operate the TV set only from a power source as indicated on the TV set or refer to the operating instructions for this information. If you are not sure of the type of power supply to your home, consult your TV set dealer or local power company. For battery operation, refer to the operating instructions.

3 Overloaded AC outlets and extension cords are dangerous, and so are frayed power cords and broken plugs. They may result in a shock or fire hazard. Call your service technician for replacement.

4 Do not allow anything to rest on or roll over the power cord, and do not place the TV set where power cord is subject to traffic or abuse. This may result in a shock or fire hazard.

5 Do not use this TV set near water — for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near swimming pool, etc.

6 If an outside antenna is connected to the TV set, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection requirements for the grounding electrode.

7 An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE


ANTENNA LEAD IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
ELECTRIC SERVICE EQUIPMENT
GROUNDING CONDUCTORS (NEC SECTION 810-21)
GROUND CLAMPS
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ARTICLE 250, PART H)
NEC - NATIONAL ELECTRIC CODE

8 TV sets are provided with ventilation openings in the cabinet to allow heat generated during operation to be released. Therefore:
- — Never block the bottom ventilation slots of a portable TV set by placing it on a bed, sofa, rug, etc.
- — Never place a TV set in a "built-in" enclosure unless proper ventilation is provided.
- — Never cover the openings with a cloth or other material.
- — Never place the TV set near or over a radiator or heat register.

9 To avoid personal injury:
- — Do not place a TV set on a sloping shelf unless properly secured.
- — Use only a cart or stand recommended by the TV set manufacturer.
- — Do not try to roll a cart with small casters across thresholds or deep pile carpets.
- — Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.

USE

10 Caution children about dropping or pushing objects into the TV set through cabinet openings. Some internal parts carry hazardous voltages and contact can result in a fire or electrical shock.

11 Unplug the TV set from the wall outlet before cleaning. Do not use liquid or an aerosol cleaner.

12 Never add accessories to a TV set that has not been designed for this purpose. Such additions may result in a hazard.

13 For added protection of the TV set during a lightning storm or when the TV set is to be left unattended for an extended period of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to product due to lightning storms or power line surges.

14 A TV set and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the TV set and cart combination to overturn.

SERVICE

15 Unplug this TV set from the wall outlet and refer servicing to qualified service personnel under the following conditions:
- A. When the power cord or plug is damaged or frayed.
- B. If liquid has been spilled into the TV set.
- C. If the TV set has been exposed to rain or water.
- D. If the TV set does not operate normally by following the operating instructions. Adjust only those controls that are covered in the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the TV set to normal operation.
- E. If the TV set has been dropped or damaged in any way.
- F. When the TV set exhibits a distinct change in performance — this indicates a need for service.

16 Do not attempt to service this TV set yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

17 When replacement parts are required, have the service technician verify in writing that the replacement parts he uses have the same safety characteristics as the original parts. Use of manufacturer's specified replacement parts can prevent fire, shock, or other hazards.

18 Upon completion of any service or repairs to this TV set, please ask the service technician to perform the safety check described in the manufacturer's service literature.

19 When a TV set reaches the end of its useful life, improper disposal could result in a picture tube implosion. Ask a qualified service technician to dispose of the TV set.

20 Note to CATV system installer.
This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

WELCOME!

Congratulations on your new television purchase! We thank you for choosing JVC.

We know you are anxious to start watching your new television, but before you operate it, please read this guide and then keep it handy for future reference. After all you just bought a great TV with a lot of terrific features, you should know what each feature is and how to use it properly!

Again, congratulations and thank you for choosing JVC! Enjoy!

TABLE OF CONTENTS

CONNECTIONS

Connections Checklist 5
Panel Diagrams 5
Cable and VCR Connections 6
Connecting to a DVD Player 8
Connecting to an External Amplifier 8
Connecting to JVC AV Compu Link 9
Connecting to a Camcorder 9

GETTING STARTED

Remote Control 10
Power 11
Adjusting Volume 11
Changing Channels 11
Remote Programming 12
CATV & Satellite Codes 12
VCR Codes 13
DVD Codes 14

MENU FUNCTIONS

Using the Menu 15
Plug In Menu
- *Introduction* 16
- *Language* 16
- *Auto Tuner Setup* 16
- *Set Clock*
  - *Auto (XDS)* 17
  - *Manual* 17
- *Finish* 17

Channel Summary 18
V-Chip 19
- *Set Lock Code* 22

Picture Settings
- *Tint* 23
- *Color* 23
- *Picture* 23
- *Bright* 23
- *Detail* 23
- *Noise Muting* 23
- *Set Video Status* 23

Sound Settings
- *Bass* 24
- *Treble* 24
- *Balance* 24
- *MTS (Multi-channel TV Sound)* 24
- *Some Sound Advice* 24

Menu Functions (Continued)

General Items
- *On/Off Timer* 25
- *TV Speaker* 26
- *Audio Out* 26
- *V4 Component-In* 26
- *Closed Caption* 26

BUTTON FUNCTIONS

Menu 27
Exit/PIP Off 27
Display 27
Video Status 27
Sleep Timer 27
BBE 28
Hyper Surround 28
Muting 28
Number Buttons (10 Key Pad) 28
100+ 28
Return+ 28
Input 29
VCR Buttons 29
DVD Buttons 29
TV/CATV Switch 29
VCR/DVD Switch 29
Light 29
PIP (Picture-In-Picture)
- *Introduction* 30
- *On/Move* 30
- *Freeze* 30
- *Swap* 30
- *Channel +/-* 30
- *Source* 30

APPENDICES

Troubleshooting 31
Limited Warranty 32
Authorized Service Centers 33
Notes 34
Specifications 36

CONNECTIONS CHECKLIST - READ ME FIRST

The Connections Checklist section of this guide is a list of ideas to keep in mind while you setup your new TV. It is designed to help us not-so-technically-minded individuals make our connections properly. If you read this section and still can't identify the plugs, connectors and components you have, please ask someone for help in making your connections.

1) Always refer to the connection instructions in the user's guide for your components first. The manufacturer will provide the most detailed information about their products.

2) Know your jacks and plugs - most are color coded:

- Yellow plugs are Video connections
- Red plugs are Right Audio connections
- White (or black) plugs are Left Audio (or Mono) connections. If your VCR is mono-sound, it will have only a white or black plug, no second red one).

3) Perform one connection at a time. If you have several accessories to connect, make sure each connection is correct by checking to see that it works properly before trying the next connection.

4) Unplug the power cord during each connection.

5) Follow the In and Out Concept. Remember In and Out - the Output jack from one device will go to the Input jack of the other. Read the jack panels, they are all labeled.

6) The AV Compu Link Cable is supplied with certain JVC devices. If you have a JVC Compu Link VCR or other piece of equipment, but don't have an AV Compu Link cable, contact your local JVC dealer.

A/V Input Plug

RF Connectors

S-Video Plug

AV Compu Link Cable

Panel Diagrams



Front Panel



Front Panel Door opened



Rear Panel

6 Connections

Cable and VCR Connections

There are three basic types of antenna or cable connections:

- If you have an antenna or have a cable system that does not require you use a cable box to select channels, please refer to **Diagram #1**.
- If you have a cable system that requires the use of a cable box to access **all** the channels, please refer to **Diagram #2**. If you cannot operate your Picture-In-Picture function using Diagram #2, try the connection shown in Diagram #3. It is possible your cable box allows the signal of only one channel at a time to be sent to your television.
- If you have a cable system that requires the use of a cable box to access **certain** premium channels, but not “basic” cable channels, please refer to **Diagram #3**.
- For your convenience, connection to a VCR is also shown in the following diagrams. A VCR is not necessary for operation of the television or Picture-In-Picture (PIP) function. You may omit the VCR from your connections if you wish.
- For instructions on connecting a VCR only, please see the Quick Setup Guide.
- For information on using PIP, please see page 30.

The connection diagrams are intended to show some basic general connections. Some cable companies may require special connections to properly use your television or 2-tuner PIP function. If you follow these diagrams and either the television or PIP does not work properly, contact your local cable operator for more connection information.



1

1) Connect the antenna or cable TV wire from the wall outlet, in to the RF Input of the two-way splitter.
2) Connect an RF cable from the one of the RF Outputs on the splitter, in to the RF Input on the back of the VCR.
3) Connect an RF cable from the other the RF Output on the splitter, in to the RF Input on the back of the TV.
4) Connect the yellow video cable out from the VCR’s Video Output, in to the TV’s Video Input jack, **OR** connect an S-Video cable from the Camcorder’s S-Video output, to the TV’s S-Video input.
5) Connect the white audio cable out from the VCR’s Left Audio Output, in to the TV’s Left Audio Input Jack.
6) Connect the red audio cable out from the VCR’s Right Audio Output, in to the TV’s Right Audio Input jack.

- If your VCR is a mono sound unit, it will have only one Audio Out jack. Connect it to the TV’s Left Audio Input.
- Please consult your VCR’s owner’s manual for more information on its operation.

Audio/Video Connections - Continued



❷

1) Connect the antenna or cable TV wire from the wall outlet, in to the RF Input of the cable box.
2) Connect an RF cable from the cable box RF Output, in to the RF Input on the back of the VCR.
3) Connect an RF cable from the RF Output on the VCR, in to the RF Input on the back of the TV.
4) Connect the yellow video cable out from the VCR's Video Output, in to the TV's Video Input jack, **OR** connect an S-Video cable from the Camcorder's S-Video output, to the TV's S-Video input.
5) Connect the white audio cable out from the VCR's Left Audio Output, in to the TV's Left Audio Input Jack.
6) Connect the red audio cable out from the VCR's Right Audio Output, in to the TV's Right Audio Input jack.



❸

1) Connect the antenna or cable TV wire from the wall outlet, in to the RF Input of the two-way splitter.
2) Connect an RF cable from the one of the RF Outputs on the splitter, in to the cable box RF Input.
3) Connect an RF cable from the Cable Box Output, in to the VCR RF Input.
4) Connect an RF cable from the other the RF Output on the splitter, in to the RF Input on the back of the TV.
5) Connect the yellow video cable out from the VCR's Video Output, in to the TV's Video Input jack, **OR** connect an S-Video cable from the Camcorder's S-Video output, to the TV's S-Video input.
6) Connect the white audio cable out from the VCR's Left Audio Output, in to the TV's Left Audio Input Jack.
7) Connect the red audio cable out from the VCR's Right Audio Output, in to the TV's Right Audio Input jack.

8 Connections

Connecting to a DVD Player



1) Connect Green cable out from DVD player “Y” Video Output, in to TV “Y” Component Input.
2) Connect Blue cable out from DVD player “P_B” Video Output, in to TV “P_B” Component Input.
3) Connect Red cable out from DVD Player “P_R” Video Output, in to TV P_R” Component Input.
4) Connect White Audio cable out from DVD Left Audio Output, in to TV Left Audio Input 2.
5) Connect Red Audio cable out from DVD Right Audio Output, in to TV Right Audio Input 2.

- Green, blue and red are the most common colors for DVD cables. Some models may vary colors, please consult the user’s manual for your DVD Player for more information.
- Be careful not to confuse the red DVD cable with the red audio cable. It is best to complete one set of connections (DVD or Audio Output) before starting the other to avoid accidentally switching the cables.
- You may also connect the DVD player to Input 4. If you use Input 4 for the DVD connection, you must set the V4 COMPONENT-IN on the initial Setup Menu to “YES” for proper display of the DVD signal.
- **NOTE:** Progressive DVD Players (players with an output scan of 31.5 KHz) will not work properly with this television.

Connecting to an External Amplifier



1) Connect the white audio cable from the TV’s Left Audio Output jack to the Amplifier’s Left Audio Input jack.
2) Connect the red audio cable from the TV’s Right Audio Output jack to the Amplifier’s Right Audio Input jack.

- See also ‘TV Speaker’ and ‘Audio Out’ on page 26 for more information on using external speakers.

Connecting to JVC AV Compu Link Capable Components

JVC's AV Compu Link feature makes playing video tapes or DVDs totally automatic. Simply insert a pre-recorded tape* into your JVC-brand VCR or DVD into your JVC DVD player and the device will automatically turn on and begin playback. At the same time, using the AV Compu Link, the VCR or DVD player sends a signal to the television telling it to turn on and switch to the proper video input

- The AV Compu Link cable may be included with the JVC AV Compu Link accessory you wish to connect. If it is not, contact an authorized JVC Service Center for part # EWP 805-012.
- AV Compu Link can only be used with JVC-brand products.



To Connect: Plug one end of the AV Compu Link cable into the AV Compu Link input on your VCR, DVD, or other Compu Link device. Plug the other end of the AV Compu Link cable into the AV Compu Link input at the rear of the television.

Connecting to a Camcorder

You may connect a camcorder to your television by using the front Input Jacks (Input 3) located under the front panel door. To access, press lightly on the door to open it. You may also connect a game console or other equipment using these jacks. Camcorders may also be connected to the television's rear input jacks.



1) Connect the yellow video cable out from the Camcorder's Video Output, in to the TV's Video Input jack **OR** connect an S-Video cable from the Camcorder's S-Video output, to the TV's S-Video input.
2) Connect the white audio cable out from the Camcorder's Left Audio Output, in to the TV's Left Audio Input Jack.
3) Connect the red audio cable out from the Camcorder's Right Audio Output, in to the TV's Right Audio Input jack.

- If your Camcorder is a mono sound model it will have only one audio jack. Connect to the TV's Left Audio Jack.

NOTES (For AV Compu Link):

** In order for the VCR playback to begin automatically, the recording tabs must be removed from the VHS tape. If the tab is in place, automatic switching will occur when you push the VCR's PLAY button.*

- *The AV Compu Link cable has a male 3.5 mm (mono) plug on each end.*
- *If your JVC-brand VCR has "A Code/B Code Remote Control Switching" (see your VCR's instruction book), using VCR A Code will switch the TV to input 1.*
- *To connect a JVC HiFi receiver or amplifier for a completely automated home theater, see the HiFi's connection instructions for detailed connection information.*
- *AV COMPU LINK EX is compatible with the following receivers: RX-664V, RX-665V, RX-668VBK, RX-774V, RX-778VBK, RX-884V, RX-888VBK, RX-1024V, RX-1028VBK, and later receiver models.*

Remote Control

RM-C301G

RM-C301G



Changing the Batteries

Be sure to use only size AA batteries.

1. Push down on the remote's back cover and slide towards the bottom to remove it.

2. Insert two AA batteries (supplied), carefully noting the "+" and "-" markings on the batteries and on the remote control. To avoid a potential short circuit, insert the "-" end first.

3. When batteries are installed, slide the cover back into place (until it clicks into position).

- If the remote control acts erratically, replace the batteries. Typical battery life is six months to one year.
- We recommend using alkaline batteries for longer battery life.

When you change the batteries, try to complete the task within three minutes. If you take longer than three minutes, the remote control codes for your VCR, DVD, and/or Cable Box may have to be reset (page 12-14).



POWER

- Press the POWER button on the remote control or the front panel of the TV. The On Timer lamp will glow red.
- Make sure the TV/CATV switch on the remote is set to TV. Move the switch to CATV only if you plan to operate a cable box. On the CATV setting the remote will only operate the cable box functions.
- To turn the power off, press the POWER button again. The On Timer lamp will go out.
- The On Timer lamp will glow red when the On/Off Timer is set (page 25), even when the TV power is off.

ADJUSTING VOLUME

To control the volume level, use the VOLUME+/- buttons on the remote control or on the TV's front panel. Use the VOLUME - button to lower the volume. Press the VOLUME+ button to raise the volume.

Press the MUTING button to instantly turn the volume to zero. Press MUTING again to return to the previous volume level.

CHANGING CHANNELS

❶ 10 key direct access

To move directly to a specific channel, press that channel's numbers on the remote's 10 key pad. For single-digit channel numbers, press "0" then the channel number. For channels above 100, press the 100+ button, then the remaining two digits on the 10 key pad.

❷ CHANNEL -/+ BUTTON

To scan through the channels, press either the CHANNEL + or CHANNEL - button. You will move through the channels in numerical order.

- After you operate the Auto Tuner Setup (page 16), all of the empty channels will be removed from scanning. When you scan you will only receive clear, active channels.

Hyperscan

With JVC's Hyperscan feature you can zip through the channels at a rate of five per second. To use Hyperscan, press and hold either the CHANNEL+ or CHANNEL- buttons. After the first few channels scan at normal speed, the rest will move by at five per second. To scan at normal speed, press and release the CHANNEL+/- button.

❸ Regular Return

Press and release the RETURN+ button to return to the previous channel viewed. For example select a channel. Then select another channel using the 10 key pad buttons. You can now flip back and forth between these two channels by pressing RETURN+.

❹ RETURN+

With RETURN+ you can program your TV to always return to a specific channel. Press and hold down the RETURN+ button for three seconds. The message, "RETURN CHANNEL PROGRAMMED!" will appear on-screen. Now when you scan through the channels, pressing RETURN+ will bring you back to your programmed channel.

To cancel the RETURN+ channel, press and hold the RETURN+ button for three seconds. The message "RETURN CHANNEL CANCELLED!" will appear on-screen.

- Pressing any number key or turning off the TV will also cancel the RETURN+ channel.

12 Remote Programming

Setting the CATV, VCR and DVD Codes

You can program your remote to operate your cable box, satellite receiver, VCR or DVD player by using the instructions and codes listed below. If the equipment does not respond to any of the codes listed below or to the code search function, use the remote control supplied by the manufacturer.

Cable Box or Satellite setup

The remote control is programmed with CATV and/or Satellite codes for power on, power off, channel up, channel down, and 10 key operation.

1) Find the CATV/Satellite brand from the list of codes shown below.
2) Slide the 2-way selector switch to “CATV”.
3) Press and hold down the DISPLAY button.
4) With the DISPLAY button held down, enter the first code number listed using the 10 key pad.
5) Release the DISPLAY button.
6) Confirm the operation of the Cable Box/Satellite receiver.

• If your CATV or Satellite box does not respond to the first code, try the others listed. If it does not respond to any code, try the Search Codes Function at the bottom of the page.

Cable Box	CODES
ABC	024
Archer	032, 025
Cableview	051, 032
Citizen	022, 051
Curtis	058, 059
Diamond	024, 032, 025
Eagle	029
Eastern	034
GC Brand	032, 051
Gemini	022, 043
General Instrument	065, 024, 025, 026, 027, 020, 021, 022, 057,023
Hamlin	040, 041, 042, 045, 058, 064
Hitachi	049, 024
Jerrold	065, 024, 025, 026, 027, 020, 021, 022, 057, 023
Macom	049, 050, 051, 054
Magnavox	033
Memorex	030
Movietime	032, 051
Oak	039, 037, 048
Panasonic	055, 056, 060, 071
Paragon	063
Philips	026, 029, 030, 052, 053, 031, 069
Pioneer	047, 062
Pulsar	051, 032

Cable Box	CODES
Puser	032
RCA	061, 070
Realistic	032
Regal	058, 064, 040, 041, 042, 045, 068
Regency	034
Rembrandt	037, 032, 051, 038
Samsung	051
Scientific Atlanta	057, 058, 059
SLMark	051, 047
Sprucer	051, 056
Stargate	032, 051
Telecaption	067
Teleview	047, 051
Texscan	044
Tocom	035, 036, 066
Toshiba	060
Unika	052, 026
Universal	022, 032
Videoway	052
Viewstar	029, 030
Zenith	063, 046
Zenith/Drake Satellite	046

Digital Satellite Systems	CODES
Echostar	100, 113, 114
Express VU	100, 113
G.E.	106
G.I.	106
Gradiente	112
Hitachi	104, 111
HNS (Hughes)	104
Panasonic	105
Philips	102, 103
Primestar	108
Proscan	106, 109, 110
RCA	106, 109, 110
Sony	107
Star Choice	104, 108
Toshiba	101
Uniden	102, 103

Search Codes Function:

1) Slide the 2-Way Mode Selector switch to CATV.
2) Press the TV POWER and RETURN+ buttons. Hold for at least three seconds and release.
3) Press TV POWER, see if the CATV or Satellite box responds.
4) If there was a response, press RETURN+. The operating codes are now set. If there was no response, repeat Step 3. If you repeat Step 3 52 times without a response, use the remote control which came with the equipment.
5) Press RETURN+ to exit.

VCR setup

The remote control is programmed with VCR codes for power on, power off, play, stop, fast-forward, rewind, pause, record, channel up, and channel down operation.

1) Find the VCR brand from the list of codes shown below.
2) Slide the first 2-way selector switch to “TV” and the other 2-way selector switch to “VCR”.
3) Press and hold down the DISPLAY button.
4) With the DISPLAY button held down, enter the first code number listed with the 10 key pad.
5) Release the DISPLAY button.
6) Confirm the operation of the VCR.

- If your VCR does not respond to the first code, try the others listed. If it does not respond to any code, try the Search Codes Function at the bottom of the page.
- Some manufacturer’s VCR’s may not respond to the TV/VCR button, even if other buttons work properly.
- To Record, hold down the REC button on the remote and press PLAY.

VCRs	CODES	VCRs	CODES	VCRs	CODES
Admiral	035	Magnavox	031, 023, 024, 086	Samsung	037, 060, 062, 033, 089
Aiwa	027, 032, 095	Marantz	003, 004, 005	Samtron	089
Akai	029, 072, 073, 074	Marta	084	Sansui	003, 026, 020, 082
Audio Dynamic	005, 006	Memorex	024, 087	Sanyo	063, 087, 091, 071
Bell & Howell	063, 071	MGA	038, 040, 047, 048, 041, 042	Scott	059, 060, 062, 067, 038, 040, 047, 048, 026, 020
Broksonic	020, 026, 094	Minolta	058, 045, 093		
Canon	023, 025	Mitsubishi	038, 040, 047, 048, 041, 042, 075, 090	Sears	063, 064, 065, 066, 056, 000, 001
CCE	043				
Citizen	064	Multitech	047, 027, 062	Shintom	075
Craig	063, 029, 064	NEC	009, 004, 005, 000	Sharp	035, 038, 060, 066
Curtis Mathes	045, 024, 027, 093	Olympic	024, 023	Signature 2000	027, 035
Daewoo	043, 059, 024, 082	Optimus	028, 021, 035, 064	Singer	075
DBX	003, 004, 005	Orion	026, 020	Sony	028, 029, 030, 053, 054, 055
Dimensia	045, 093	Panasonic	023, 024, 021, 022	SV 2000	027
Emerson	043, 026, 077, 061, 025, 042, 020, 076	Penney	024, 058, 045, 053, 003, 004, 005, 093	Sylvania	031, 023, 024, 027
				Symphonic	027, 061
Fisher	053, 056, 057, 055, 071, 091	Pentax	058, 005, 045, 093	Teshiro	064
Funai	027, 026, 020, 000	Philco	031, 024, 027, 023, 026, 020, 049	Tatung	003, 004, 005
G.E.	033, 045, 024			Teac	003, 004, 027, 005
Go Video	037, 051, 049, 050, 052	Philips	031, 023, 024, 056	Technics	021, 022, 023, 024
Goldstar	064	Pioneer	023	Teknika	024, 027, 070
Gradiente	083, 084, 081, 000, 001	Prosonic	045, 058, 023, 024, 031, 046, 059, 060, 033, 057, 093	Toshiba	058, 046, 079
Hitachi	023, 045, 058, 027, 061, 093			Vector Research	005
Instant Replay	024, 023	Quasar	021, 022, 023, 024	Wards	035, 038, 067, 044, 064
Jensen	003	Radio Shack	033, 024, 063, 036, 057, 040, 027	Yamaha	063, 003, 004, 005
JVC	000, 001, 002, 003, 004, 005			Zenith	044, 062, 064, 094
Kenwood	003, 004, 064, 005	RCA	033, 045, 058, 023, 024, 031, 046, 059, 060, 053, 094, 095, 057, 093		
LXI	027, 094, 058, 095, 096, 063, 057				
		Realistic	024, 063, 036, 057, 040, 027		

Search Codes Function:

1) Slide the first 2-way selector switch to “TV” and the other 2-way selector switch to “VCR”.
2) Press the VCR POWER and RETURN+ buttons. Hold for at least three seconds and release.
3) Press VCR POWER, see if the VCR responds.
4) If there was a response, press RETURN+. The operating codes are now set. If there was no response, repeat Step 3. If you repeat Step 3 80 times without a response, use the manufacturers remote control which came with the VCR.
5) Press RETURN+ to exit.

14 Remote Programming

DVD setup

The remote control is programmed with DVD codes for power on, power off, play, stop, fast-forward, rewind, previous chapter, next chapter, tray open/close, and still/pause operation.

1) Find the DVD player brand from the list of codes shown below.
2) Slide the first 2-way selector switch to “TV” and the other 2-way selector switch to “DVD”.
3) Press and hold down the DISPLAY button.
4) With the DISPLAY button held down, enter the first code number listed with the 10 key pad.
5) Release the DISPLAY button.
6) Confirm the operation of the DVD player.

- If your DVD player does not respond to the first code, try the others listed. If it does not respond to any code, try the Search Codes Function at the bottom of the page.
- After you program your remote, some DVD buttons may not work properly. If some buttons do not work properly, use the remote control which came with your DVD player.

DVD Player	CODES
Aiwa	043
Apex	040
Denon	020, 037
Hitachi	030, 031
JVC	000
Kenwood	035
Konka	039
Mitsubishi	025
Onkyo	041
Orittron	044
Panasonic	020
Philips	023, 036
Pioneer	022
Raite	033
RCA	021, 026
Sampo	034
Samsung	030
Sharp	026
Silvania	036
Sony	024, 045, 048, 047
Technics	020
Toshiba	023
Wave	042
Yamaha	020
Zenith	027, 032

Search Codes Function:

1) Slide the first 2-way selector switch to “TV” and the other 2-way selector switch to “DVD”.
2) Press the DVD POWER and RETURN+ buttons. Hold for at least three seconds and release.
3) Press DVD POWER, see if the DVD player responds.
4) If there was a response, press RETURN+. The operating codes are now set. If there was no response, repeat Step 3. If you repeat Step 3 30 times without a response, use the manufacturers remote control which came with the DVD player.
5) Press RETURN+ to exit.

Using this Guide

Certain symbols are used throughout this guide to help you learn about the features of your new television. The ones you will see most frequently are:

▲▼ Up and Down arrows mean press the CHANNEL UP or CHANNEL DOWN buttons. Pressing the UP or DOWN buttons let you:

- Move vertically in a main menu screen
- Move through a submenu screen
- Move to the next letter, number, or other choice in a submenu
- Back up to correct an error
- Scan through TV channels (when not in a menu screen)

◀▶ Left and right arrows mean press the VOLUME LEFT or VOLUME RIGHT buttons to:

- Select a highlighted menu item
- Select an item in a submenu
- Select numbers in certain menu options
- Turn the volume up or down (when not in a menu screen)

The "Press Button" icon means you should press the button named on your remote control. (Button names appear in SMALL CAPITAL LETTERS.)

The 'Helping Hand' points to the highlighted or selected item in a menu.

The Onscreen Menus:

To bring up the onscreen menu, press the MENU button on the remote control. The item that appears in yellow is the one currently selected. If you press the MENU button again, the onscreen display will skip to the next menu screen.

Menu Screen Order → 2 → 4 → 5 → 6 →

The "Plug In Menu' will appear the first time the TV is plugged in.

Notes*: Menus shown in this book are illustrations, not exact replications of the television's onscreen displays.*

If you use the Menu button on the TV's front panel instead of the remote, an additional menu screen showing channel number and input will appear between menus 1 and 2.



❶ *Initial Setup Items*



❷ *Picture Settings*



❸



❹ *Sound Settings*



❺ *General Items*



❻



16 Plug In Menu

Introduction

The Plug In Menu comes up automatically when you first turn on the TV after plugging it in. The Plug In Menu helps you to get your TV ready to use by letting you set your preferences for:

- *The Language in which you want the onscreen menus to appear,*
- *The Auto Tuner Setup of which channels you wish to receive,*
- *Setting the TV's clock to the correct time so your timer functions will work properly.*

Descriptions of each of the Plug In Menu features appear on this page and the next. We recommend you complete the Plug In Menu setup first so your TV is set up just the way you want, right away.

Language

You can choose to view your onscreen menus in three languages: English, French, or Spanish.

Press the MENU button

▲▼ To LANGUAGE

◀▶ To choose a language

ENGLISH → FRENCH → SPANISH →

EXIT/PIP OFF when finished

Auto Tuner Setup

In Auto Tuner Setup, the TV automatically scans through all available channels, memorizing the active ones and skipping over blank ones or channels with weak signals. This means when you scan (using the CHANNEL +/- buttons) you will receive only clear, active channels.

Press the MENU button

▲▼ To AUTO TUNER SETUP

◀▶ To operate



◀▶ To choose CABLE or AIR

▲▼ To move to START

◀▶ To start Auto Tuner Setup



Programming will take approximately 1 to 2 minutes.

- Noise Muting will not work during Auto Tuner Setup.

NOTE:

• If you exit the Plug In Menu, or wish to change your preferences later, all the Plug In Menu options can be found in the regular onscreen menus.

Set Clock

Before you use any of your TV's timer functions, you must first set the clock. You may precisely set your clock using the XDS time signal broadcast by most Public Broadcasting stations. To set the clock using the XDS signal:

Enter the channel number of your local PBS station.

Press MENU

▲▼ To Set Clock

◀▶ To operate

◀▶ To Auto

MODE	AUTO	MANUAL
TIME ZONE		EASTERN
D.S.T.	ON	OFF
FINISH		

▲▼ To Time Zone

◀▶ To select your time zone

ATLANTIC ◀▶ EASTERN ◀▶ CENTRAL ◀▶ MOUNTAIN ◀▶ HAWAII ◀▶ ALASKA ◀▶ PACIFIC

▲▼ To move to Daylight Savings Time (D.S.T.)

◀▶ To turn D.S.T. ON or OFF

▲▼ To FINISH

◀▶ To save settings and exit

• If you do not have a PBS station in your local area, you will have to set the clock manually. See 'Set Clock - Manual' at the top of the next column for instructions.

• The Daylight Savings Time feature automatically adjusts your TV's clock for Daylight Savings. The clock will move forward one hour at 2:00 am on the first Sunday in April. The clock will move back one hour at 2:00 am on the last Sunday in October.

Set Clock - Manual

To set your clock manually (without using the XDS signal), choose MANUAL from the Set Clock menu and follow the steps below.

MODE	AUTO	MANUAL
TIME		--:-- --
START CLOCK		

▲▼ To move to the hour

◀▶ To set the hour

▲▼ To move to minutes

◀▶ To set the minutes

▲▼ To move to START CLOCK

◀▶ To start clock and exit

THANK YOU !!

Finish

Once you have the items in the Plug In Menu set to your personal preferences, move to the Finish option to save your settings.

▲▼ To FINISH

◀▶ To save settings and exit

• You can change the preferences you set in the Plug In Menu at any time using the regular JVC onscreen menu system.

NOTES:

• *You will have to reset the clock after a power interruption. You must set the clock before operating any timer functions.*

18 Channel Summary

Channel Summary

Channel Summary allows you to customize the line-up of channels received by your TV. You can add or delete channels from the line-up or prevent any unauthorized viewers from watching any or all 181 channels.

Press the MENU button

▲▼ To CHANNEL SUMMARY

◀▶ To operate

The Channel Summary screen (below) will now be displayed with the channels set to scan marked with an "✓". You can delete channels from the scan by removing the "✓". If any channels were missed during Auto Tuner Setup and you wish to add them, you may by placing an "✓" next to the channel number.

CHNO.	SCAN	🔒	CHNO.	SCAN	🔒
01			06	✓	
02	✓		07		
03	✓		08		
04	✓		09	✓	
05	✓		10	✓	

▲▼ To the SCAN column

◀▶ To include or delete from scan

EXIT/PIP OFF when finished

Channel Summary - Lock

▲▼ To CHANNEL SUMMARY

◀▶ To operate

▲▼ To the Lock Column

ZERO to lock or unlock that channel

CHNO.	SCAN	🔒	CHNO.	SCAN	🔒
01	✓		06	✓	
02	✓		07		🔒
03	✓		08		🔒
04	✓		09	✓	
05	✓		10	✓	

EXIT/PIP OFF when finished

Channel Guard Message

When a viewer attempts to watch a guarded channel, the following message appears:

```
THIS CHANNEL IS LOCKED BY
CHANNEL GUARD.
PLEASE ENTER LOCK CODE BY
10 KEY PAD TO UNLOCK IT.

NO. - - - -
```

To watch a channel that you have locked, enter the Lock Code using the 10 key pad (see “Set Lock Code” - at the top of the next column).

If the wrong code is entered, this message will flash on the screen:

```
INVALID LOCK CODE !
```

The channel cannot be accessed until the correct code is entered.

- Once a channel has been unlocked, it will remain unlocked until the television is turned off.

NOTE:

- *Some cable systems experience interference from radio frequencies on cable Channel 95. You may delete this channel from your scan by removing the "✓" next to it on the Channel Summary screen.*

V-Chip

Your TV is equipped with V-Chip technology which enables TV Parental Guideline and Movie (MPAA) Guideline controls. V-Chip technology allows you to program your TV to receive, or not to receive, programs based on content according to the guidelines. Programs which exceed the ratings limits you set will be blocked.

When a viewer attempts to watch a blocked channel, this message appears:



To watch a blocked channel, enter the lock code (page 14) using the 10 key pad.

To set up the TV Parental Guideline Ratings:

Press the MENU button

▲▼ To V-CHIP

◀▶ To operate (Lock icon will appear)

Press ZERO to access the V-Chip menu



◀▶ To turn V-Chip ON or OFF

▲▼ To move to SET US TV RATINGS

◀▶ To operate (see page 19 for details)



Viewing Guidelines

- V/FV is for VIOLENCE/FANTASY VIOLENCE
- S stands for SEXUAL CONTENT
- L stands for strong LANGUAGE
- D stands for suggestive DIALOG

U.S. PARENTAL RATING SYSTEMS

Programs with the following Ratings are appropriate for Children.

❒ **TV Y is Appropriate for All Children.**
Programs are created for very young viewers and should be suitable for all ages, including children ages 2 - 6.

❒ **TV Y7 is for Older Children.**
Most parents would find such programs suitable for children 7 and above. They may contain some mild fantasy violence or comedic violence, which children should be able to discern from reality.

Programs with the following Ratings are designed for the entire audience.

❒ **TV G stands for General Audience.**
Most parents would find these programs suitable for all age groups. They contain little or no violence, no strong language, and little or no sexual dialog or situations.

❒ **TV PG Parental Guidance Suggested.**
May contain some, but not much, strong language, limited violence, and some suggestive sexual dialog or situations. It is recommended that parents watch these programs first, or with their children.

❒ **TV 14 Parents Strongly Cautioned.**
Programs contain some material that may be unsuitable for children under the age of 14 including possible intense violence, sexual situations, strong coarse language, or intensely suggestive dialog. Parents are cautioned against unattended viewing by children under 14.

❒ **TV MA Mature Audiences Only.**
These programs are specifically for adults and may be unsuitable for anyone under 17 years of age. TV MA programs may have extensive V, S, L, or D.

20 V-Chip

Directions to Block Viewing:

Line up the cursor in the column (TV PG, TV G, etc.) with the content row (V/FV, S, etc.) and press the ▲or▼ to move the cursor to the correct location. Press ◀ or ▶ to turn the locking feature on or off. An item is locked if the 🔒 icon appears instead of a "—".

For example. To block viewing of all TV 14 shows:

Move the cursor to the top row of that column and add a lock icon. Once you've put a lock on the top row, everything in that column is automatically locked.

▲▼ To the TV 14 Column

◀▶ To turn on the lock



▲▼ To FINISH

◀▶ To save settings and exit

• If you want to change the setup, move the cursor to the top column and change the lock icon to "—". You may then select individual categories to block.

Special Note about Ratings

Some programs are not broadcast with a ratings signal. Therefore, even if you setup V-Chip ratings limits, these programs will not be blocked. Parents are cautioned to preview the contents of these programs or movies.

Directions to set up Movie Ratings:

Press the MENU button

▲▼ To V-CHIP

◀▶ To operate (Lock icon 🔒 appears)

Press ZERO to access V-Chip setup options

▲▼ To SET MOVIE RATINGS

◀▶ To enter movies menu



❒ **NR - Not Rated.**
This is a film which has no rating. In many cases these films were imported from countries which do not use the MPAA ratings system. Other NR films may be from amateur producers who didn't intend to have their film widely released.
NR (Not Rated) Programming may contain all types of programming including children's programming, foreign programs, or adult material.

❒ **G – General Audience.**
In the opinion of the review board, these films contain nothing in the way of sexual content, violence, or language that would be unsuitable for audiences of any age.

❒ **PG – Parental Guidance.**
Parental Guidance means the movie may contain some contents such as mild violence, some brief nudity, and strong language. The contents are not deemed intense.

❒ **PG-13 – Parents Strongly Cautioned.**
Parents with children under 13 are cautioned that the content of movies with this rating may include more explicit sexual, language, and violence content than movies rated PG.

NOTE (For Canadian Viewers):

• *V-Chip function is based on specifications for the United States and therefore may not work properly in Canada.*

- ❒ **R Restricted.**
  These films contain material that is explicit in nature and is not recommended for unsupervised children under the age of 17.
- ❒ **NC-17 No One Under 17.**
  These movies contain content which most parents would feel is too adult for their children to view. Content can consist of strong language, nudity, violence, and suggestive or explicit subject matter.
- ❒ **X No One under 18.**
  Inappropriate material for anyone under 18.

Directions to Block Movie Viewing:

To block viewers from any or all of these ratings categories, press the ▲or▼to move the cursor to the correct location. Press the ◀ or ▶ buttons to turn the locking feature on or off. An item is blocked if the 🔒 icon appears instead of a "—".

For example, to block viewing of X and NC-17 rated from shows:

▲▼ To the X Column

◀▶ To turn on the lock



▲▼ To the NC-17 Column

◀▶ To turn on the lock



▲▼ To FINISH

◀▶ To save settings and exit

Notes About Unrated Programs:

Unrated programming refers to any programming which does not contain a rating signal. Programming on television stations which do not broadcast rating signals will be placed in the "Unrated Programming" category.

Examples of Unrated programs:

Emergency Bulletins
Locally Originated Programming
News
Political Programs
Public Service Announcements
Religious Programs
Sports
Weather
Some Commercials

- TV programs or movies that do not have rating signals will be blocked if the Unrated Category is set to LOCK.

Directions to Block Unrated Programs:

You can block programs that are not rated.

Press the MENU button

▲▼ To V-CHIP

◀▶ To operate (The lock icon 🔒 appears)

Press ZERO to access V-Chip setup options

▲▼ To UNRATED

◀▶ To View or Block

Press EXIT/PIP OFF when done

NOTES:

- *In order for V-Chip settings to take effect,* ***V-Chip settings must be turned ON in the V-Chip menu (page 19).***
- *You can automatically unblock all of your restrictions by turning V-Chip settings OFF in the V-Chip menu (page 19).*
- *You can always unblock a restriction by re-entering the V-Chip menu and removing the lock icon.*

22 V-Chip

Accessing V-Chip Information:

To access Rating information about a certain program, press the V-CHIP button while viewing that program. A display like this will appear:

If you decide you want to block this category of viewing, press "0" while the above screen is visible, and all programs from that category will be blocked.

Example 1:

If you want to set your V-Chip settings to block *all* programming above TV PG:

Press ZERO when TV-PG is displayed



All Programming above TV PG will be blocked.

Example 2:

If you want to set your V-Chip settings to block all programming above a current setting such as TV PG-V (with violence):

Press ZERO when TV-PG - V is displayed



All Programming above TV PG with Violence will be blocked!

• For Children's programming you can block TV-Y and Y programs by Pressing “0” when Y is displayed during a program. Programming for audiences other than children’s audiences will not be affected.

Set Lock Code

Channel Guard and V-Chip settings are protected by a four-digit Lock Code. Your TV comes pre-set with a Lock Code of "0000". You may change the code to any four-digit number you wish. To change the Lock Code, follow the steps below.

Press the MENU button

▲▼ To SET LOCK CODE

◀▶ To operate

The padlock icon appears

Press ZERO to access the Lock Code



The first digit will be highlighted

◀▶ To select the number

▲▼ To move to the next digit

Continue to follow these directions for all four numbers

▲▼ To FINISH

◀▶ To save settings and exit

Your Lock Code is now set.

NOTES:

- *After a power interruption you must reset the Lock Code.*
- *Write your Lock Code number down and keep it hidden from potential viewers.*
- *If you forget the Lock Code, a new code may be set using the steps listed above.*

Tint

Tint allows you to adjust the levels of red and green in your TV picture.

▲▼ To TINT
▶ To increase the levels of green
◀ To increase the levels of red
▲▼ To move to the next setting

Color

The color function lets you make all the colors in the TV picture appear either more vivid or subtle.

▲▼ To COLOR
▶ To make the colors more vivid
◀ To make the colors more subdued
▲▼ To move to the next setting

Picture

Picture allows you to adjust the levels of black and white on the TV screen, giving you a darker or brighter picture overall.

▲▼ To PICTURE
▶ To increase the level of contrast
◀ To decrease the level of contrast
▲▼ To move to the next setting

Bright

You can adjust the overall brightness of the TV picture with the Bright control.

▲▼ To BRIGHT
▶ To lighten the picture
◀ To darken the picture
▲▼ To move to the next setting

Detail

The Detail feature adjusts the level of fine detail displayed in the picture.

▲▼ To DETAIL
▶ To make the picture sharper (more details)
◀ To make the picture smoother (less detail)
▲▼ To move to the next setting

Noise Muting

This feature inserts a blank blue screen over channels which are not broadcasting or are too weak to be received clearly.

Press the MENU button
▲▼ To NOISE MUTING
◀▶ To turn Noise Muting ON or OFF

• Noise Muting will not work during Auto Tuner Setup or when you operate Channel Summary.

Set Video Status

With Set Video Status, you can save your own set of picture quality adjustments as "Choice" and have access to them at the touch of a button.

Press the MENU button
▲▼ To SET VIDEO STATUS
◀▶ To operate



◀▶ To set the TINT levels
▲▼ To move to the next option

Repeat these steps until all levels are set.

▲▼ To SAVE AS CHOICE
◀▶ To save settings and exit

• You must use SAVE AS CHOICE to exit the Set Video Status menu, otherwise your preferences will not be saved.

• You can access your "Choice" settings at any time by pressing the VIDEO STATUS button on the remote control.

NOTE:

• The setting screen will disappear if you do not make any adjustments or move to the next setting in approximately three seconds. Any changes you have made to picture settings up to that point will be stored. You can exit the Picture Settings menu at any time by pressing the EXIT/PIP OFF button on the remote control.

24 Sound Settings

Bass

You can increase or decrease the level of low-frequency sound in the TV's audio with the Bass adjustment.

Press the MENU button

▲▼ To BASS

▶ To increase the bass

◀ To decrease the bass

▲▼ To move to the next setting

Treble

Use Treble to adjust the level of high-frequency sound in your TV's audio.

Press the MENU button

▲▼ To TREBLE

▶ To increase the treble

◀ To decrease the treble

▲▼ To move to the next setting

Balance

Adjust the level of sound between the TV's two speakers with the Balance setting.

Press the MENU button

▲▼ To BALANCE

▶ To shift the balance towards the right speaker

◀ To shift the balance towards the left speaker

▲▼ To move to the next setting

MTS (Multi-Channel Television Sound)

MTS technology allows several audio signals to be broadcast at once, giving you a choice in what you wish to hear with a TV program. In addition to mono or stereo sound, an MTS broadcast may also include a Second Audio Program (SAP).

Press the MENU button

▲▼ To MTS



◀▶ Select the mode

(The ON AIR arrow tells you if a broadcast is in Stereo and/or contains an SAP).

• Keep the TV in STEREO mode to get the best sound quality. The sound will work in STEREO mode even if a certain broadcast is in MONO sound only.
• Choose the MONO setting to reduce excessive noise on a certain channel or broadcast.
• Selecting SAP will allow you to hear an alternative soundtrack, if one is available.

Some Sound Advice

You can tell if a program is broadcast in stereo by the position of the ON AIR arrow in the MTS menu screen. Unfortunately, while many programs are originally broadcast in stereo, some cable companies may "squash" the transmission to mono sound because they have only mono equipment. If you are connected to a cable system, the sound quality is determined by the cable company. If they broadcast only in mono, you will receive only mono sound, even if the program was aired in stereo.

Fortunately, most stereo programs are broadcast by the major television networks. If you connect an antenna to your TV instead of cable and set the tuner mode in Auto Tuner Setup to "Air" instead of "Cable" you will be able to pick up stereo broadcasts in their original stereo format

NOTE:

• *You can leave the Sound Settings menu at any time by pressing the EXIT/PIP OFF button on the remote control.*

On/Off Timer

The On/Off timer lets you program your television to turn itself on or off. You can use it as an alarm to wake up, to help you remember important programs, or as a decoy when you're not home.

Press the MENU button

▲▼ To ON/OFF TIMER

◀▶ To operate (begins with ON TIME)

ON TIME		7:00 PM
OFF TIME		10:00 PM
CHANNEL		02
MODE	ONCE	EVERYDAY
ON/OFF TIMER		YES NO
	FINISH	

◀▶ To set the hour (AM/PM) you want the TV to turn on

▼ To move to minutes

◀▶ To set the minutes

▼ To accept ON TIME and move to OFF TIME (the time the TV will turn off). Set the OFF TIME the same way as ON TIME

▼ To accept OFF TIME and move to CHANNEL

◀▶ To select channel

▼ To move to MODE

◀▶ Choose ONCE or EVERYDAY

▼ To ON/OFF TIMER

◀▶ Choose YES to accept the timer setting, choose NO if you don't wish to accept

▼ To FINISH

◀▶ To save settings

Timer Note:

If the television is on when a timed event is about to start a Timer Preview window will appear. The Timer Preview window will appear in the lower right corner of the screen seven seconds before the timer is programmed to begin. When the timer activates, the Preview picture will become the main picture.



Seven seconds before Timer Activates....



(Preview of ON/OFF Timed Program)

Seven seconds later...



Timer Activates

NOTE:

• *On/Off Timer cannot be set to locked or guarded channels. In order for the On/Off Timer to work, the clock must be set. After a power interruption Timer settings must be reset.*

26 General Items

TV Speaker

If your TV is connected to a stereo system, you can turn off the TV speakers and listen to the audio through your stereo.

Press the MENU button

▲▼ To TV SPEAKER

TV SPEAKER	ON	OFF

◀▶ To turn the TV's speakers ON or OFF

EXIT/PIP OFF when finished

• Before you turn the TV Speaker setting from OFF to ON, **make sure that the TV volume level is low!** If the TV volume is set too high, the sound level will be extremely loud.

• After a power interruption, the TV Speaker settings will return to "ON".

Audio Out

If your television is connected to an external speaker source, Audio Out gives you the option of controlling the volume level with your TV's remote control.

Press the MENU button

▲▼ To AUDIO OUT

AUDIO OUT	VARI	FIX

◀▶ To VARI or FIX

EXIT/PIP OFF when finished

VARI: Lets you adjust the volume of the external speakers using the VOLUME +/- buttons on your TV's remote control.

FIX: The volume of the external speakers is adjusted using the audio device's remote control.

V4 Component-In

Get the best quality video from your DVD player by using this setting and the DVD inputs at the rear of the television. Set either to YES for component input (for DVD) or to NO for composite video input (for a regular VCR).

Press the MENU button

▲▼ To V4 COMPONENT-IN

V4 COMPONENT-IN	YES	NO

◀▶ To turn the input ON or OFF

EXIT/PIP OFF when finished

• This option should be used with DVD players only. For information on connecting VCR's see page 6. For more information on connecting a DVD player, see page 8.

Closed Caption

Use this function to display the Closed Captioning text onscreen (when included in a broadcast).

Press the MENU button

▲▼ To CLOSED CAPTION

◀▶ To operate

MODE	:	CAPTION			
CAPTION	:	CC1	CC2	CC3	CC4
TEXT	:	T1	T2	T3	T4
		FINISH			

◀▶ To select CAPTION, TEXT, or OFF

▲▼ To CAPTION or TEXT

◀▶ To select a caption (CC1 to CC4) or text channel (T1 to T4)

▲▼ To accept that selection and move to FINISH

◀▶ To save settings and exit

NOTES:

• *Closed Captions subtitles are usually found on caption channel CC1. Some programs may include additional text information which is usually found on text channel T1. The other channels are available for future use.*

• *Closed captioning may not work correctly if the signal being received is weak or if you are playing a video tape.*

• *Most broadcasts containing Closed Captioning will display a notice at the start of the program.*

• External Speakers: *When using external speakers or amplifiers, shut off the TV Speakers (see 'TV Speakers') above.*

Menu

The MENU button allows you to access JVC's onscreen menu system. Press MENU to activate the onscreen menu system.

• See individual topics (like "Sound Settings) for specific information on using menus.

Exit/PIP Off

Press the EXIT/PIP OFF button to leave a menu screen or to turn off the PIP feature (page 30).

Display

The Display screen shows the current status of timers and inputs.

Press the DISPLAY button

07	
NOW	12:20 PM
SLEEP TIMER	OFF
ON/OFF TIMER	EVERYDAY
ON TIME	7:00 PM
OFF TIME	10:00 PM

- The channel or AV input (Channel 07)
- The current time (12:20 pm)
- Sleep Timer status/minutes remaining (The Sleep Timer is off)
- On/Off Timer status (Set to turn on everyday at 7:00 PM, off at 10:00 PM)
- Each Press of the DISPLAY button changes the display mode:

→ Display ⟶ Time ⟶ Channel ⟶ Off →

Display - Full screen shown above

Time - Shows the current time only

Channel - Shows the current channel

Off - Turns Display off

• You may also turn off the Display at any step by pressing EXIT/PIP OFF.

Video Status

The VIDEO STATUS button gives you a choice of three TV picture display settings, including a display of your own preferences.

Standard - Resets the picture display to the factory settings.

Choice - Displays the setting levels you specified on the "Set Video Status" Menu (see page 23).

Theater - Gives a rich, film-like look to video.

Press the VIDEO STATUS button

→ CHOICE ⟶ THEATER ⟶ STANDARD →

Sleep Timer

The Sleep Timer can turn the TV off for you after you fall asleep. Program it to work in intervals of 15 minutes, for a total time of up to 180 minutes.

Press the SLEEP TIMER button

→ 0 15 30 45 60 75 90 105 120 135 150 165 180 →

Sleep Timer Message

20 seconds before the automatic shutoff, this message will appear:

GOOD NIGHT!!
PUSH SLEEP TIMER BUTTON
TO EXTEND.

You then have 20 seconds to press the Sleep Timer button to delay the shutoff for another 15 minutes.

NOTE:

• Please note that if the Clock, Sleep Timer or On/Off Timer are not set, the Display screen will show: "Clock Not Set", "Sleep Timer OFF", and "On/Off Timer Off" respectively.

28 Button Functions

BBE

BBE high definition audio adds natural, clear and extraordinary sound quality to any program. Turn BBE On or Off using the BBE button.

Hyper Surround

Creates a deep, three-dimensional sound effect by channeling the audio through the TV's front-firing speakers. Press the HYPER SURROUND button to turn the effect on or off.

Muting

The MUTING button instantly turns the volume down completely when you press it.

MUTING

The volume level will instantly go to zero.

• To restore the volume to its previous level, press MUTING again.

Number Buttons - 10 Key Pad

To move directly to a specific channel, enter the channel number with the number buttons on the remote. For example, to move to Channel 7:

0 (zero)

7 (seven)

100+ Button

Use the 100+ button to directly access channels above Channel 99. For example to move to channel 124:

100+

2 (two)

4 (four)

Return+

The RETURN+ button has two functions:

Return - Returns to the channel viewed just before the channel currently onscreen.

Return+ - Lets you program a specific channel to return to while scanning through the channels.

RETURN+ and hold for three seconds

Scan using the Channel+/- buttons

RETURN+

You will return to your programmed channel.

• To cancel your Return+ channel, press and hold the RETURN+ button for three seconds. The message "RETURN CHANNEL CANCELLED!" will appear.
• Return+ works only with CHANNEL+/-. Pressing any number key will cancel Return+.
• Return+ does not effect the PIP channel.
• For more information on Return and Return+, please see page 11.

NOTE:

• BBE is a registered trademark of BBE Sound, Inc. For U.S., licensed from BBE Sound, Inc. under USP 4638258, 4482866 and 5510572. For Canada, licensed from BBE Sound, Inc. BBE is a registered trademark of BBE Sound, Inc.

Input

Selects the signal input source for the television: TV (for Antenna or Cable) or Video1, 2, 3, or 4 for video devices like VCR's, DVD players, or camcorders.

INPUT



VCR Buttons

You can use this remote control to operate the basic functions of your VCR. These functions include: play, record, rewind, fast-forward, stop, pause, channel scan, TV / VCR, power on, and power off.

Move the selector switch to VCR to operate.

• The remote is preset with the code 000 to control JVC-brand VCR's. For any other manufacturer's brand VCR, please see the code chart and instructions on page 13.

DVD Buttons

You can also use this remote control to operate the basic functions of your DVD player. These functions include: play, rewind, fast-forward, stop, still/pause, previous/next, tray open/close, power on, and power off.

Move the selector switch to DVD to operate.

• The remote is preset with the code 000 to control JVC-brand DVD players. For any other manufacturer's brand DVD player, please see the code chart and instructions on page 14.

TV/CATV Switch

Use either the television's own tuner or a cable box to select channels. Set this switch to TV to operate the television's built-in tuner. Move the switch to CATV to operate a cable box.

• See page 12 for information on programming your remote for cable box operation.

VCR/DVD Switch

You can control a VCR or DVD player with the buttons on the lower part of the remote control. Use the VCR/DVD selector switch to choose either VCR or DVD operation.

• See pages 13 and 14 for information on programming your remote with VCR and DVD operating codes.

Light

The RM-301G remote includes illuminated buttons for key features like CHANNEL +/- and VOLUME +/-. Press the LIGHT button to turn the illumination on.

LIGHT

Button Functions - PIP

PIP (Picture-In-Picture)

PIP displays two separate pictures on screen. Your television has 2-Tuner PIP, meaning you can view pictures from two *different* channels simultaneously. A special set of PIP control buttons are located on the upper part of the remote control. Descriptions of each button appear on this page.

ON/MOVE

Turn PIP on by pressing the ON/MOVE button.

(PIP) ON/MOVE



EXIT/PIP OFF to turn PIP off

Once PIP is turned on, you can move the PIP window to any of the TV's main picture's four corners with the ON/MOVE button.

ON/MOVE



- Each press of ON/MOVE will shift the PIP window to a different corner.

FREEZE

Use the FREEZE button to lock a single, still image onto the PIP window.

FREEZE

- If PIP is off when FREEZE is pressed, a snapshot of the main screen is taken and placed in the PIP window.
- If PIP is on when FREEZE is pressed, the image in the window when the button was pressed is held.

SWAP

You can exchange the channel displayed on the main screen for the one shown in the PIP window by pressing SWAP.

SWAP

CHANNEL +/- For PIP

Like the main CHANNEL +/- buttons, CHANNEL +/- for PIP lets you scan through the channels in the PIP window.

CHANNEL +/-

- Direct channel selection with the 10 key pad for PIP is not possible.

SOURCE

You can select the signal source for the PIP window image.

SOURCE



- If the PIP does not have a signal, the window will be blue.
- If you connect a DVD to Video-2 or Video-4, the PIP window will be blue.

NOTES:

- *The PIP window is 1/9 the size of the full screen.*
- *PIP will not display blocked channels or programs. A blue screen will display instead.*

PROBLEMS	CHECK
There is no power	• See if the power cord becams unplugged. • Check for a blown fuse or circuit breaker or a power outage.
There is no picture or sound	• The antenna could be disconnected. • The input mode (TV / Video) could be set improperly. See page 29. • The tuner (Auto Tuner Setup) could be set improperly. See page 16. • The TV station may be having difficulties. Check to see if other stations are working.
Remote control is not operating properly or at all	• Check to see that the batteries are still working and properly installed. • Make sure the remote has a clear sight path to the TV. • Check that the TV/CATV switch is in the proper position.
You cannot select a certain channel	• You may be too far from the TV. You must be within 25 feet (7 meters). • Make sure the channels have been programmed. See "Channel Summary", page 18. • Check to see if the channel is locked. See "Channel Summary - Lock" page 18.
The power turns off by itself	• Make sure the set did not become unplugged. • Perhaps the On/Off Timer is set. See page 25. • Check to see if the Sleep Timer was set. See page 27.
The clock is wrong	• The power was interrupted and the clock was not reset. See page 17.
The On Timer is blinking	• There is a problem with the TV. Unplug the set and call for service.
The color quality is poor	• Tint and Color may be improperly adjusted. See page 23. • The Video Status mode may be turned to the wrong setting. See page 27.
There are lines across the picture	• There could be interference from another electrical appliance, such as a computer, another TV or VCR. Move any such appliances further away from the TV.
The picture is spotted	• There could be interference from a high-wattage appliance, like a hairdryer or vacuum, operating nearby. Move the antenna away from the appliance or change to a coaxial cable connection which is less prone to interference.
There are double pictures (ghosts)	• A building or passing airplane can reflect the original signal and produce a second, slightly delayed one. Adjust your antenna position.
Picture is snowy (image noise)	• Your antenna may be damaged, disconnected or turned. Check the antenna connection page 6 and in your Quick Setup Guide. If the antenna is damaged, replace it.
Screen is 80% black	• The Closed Caption Text mode is on. Turn it off in the Closed Caption Menu, page 26.
Stereo or bilingual programs can't be heard	• Make sure the MTS settings are correct. See "MTS" on page 24.
There is no sound from the TV's speakers	• The TV Speaker option may be turned off. See page 28.
Static electricity	• It is normal to feel static electricity if you brush or touch the screen.
You hear occasional crackling sounds	• It is normal for the TV to make crackling sounds when first turned on or off. Unless the sound or picture becomes abnormal, this is fine.

Limited Warranty

JVC

For Canadian model televisions, see separate sheets for Warranty/Garantie and JVC Authorized Service Centers in Canada.

JVC COMPANYOF AMERICAwarrants this product and all parts thereof, except as set forth below ONLYTO THE ORIGINALPURCHASER AT RETAIL to be FREE FROM DEFECTIVE MATERIALS AND WORKMANSHIPfrom the date of original retail purchase for the period shown below (the "Warranty Period") (PICTURE TUBE is covered for Two (2) years.)

Parts	Labor
1 YEAR	1 YEAR

THIS LIMITED WARRANTY IS VALID ONLY IN THE FIFTY (50) UNITED STATES, THE DISTRICT OF COLUMBIA AND COMMONWEALTH OF PUERTO RICO.

WHAT WE WILL DO:
If this product is found to be defective within the warranty period, JVC will repair or replace defective parts at no charge to the original owner. Such repair and replacement services shall be rendered by JVC during regular business hours at JVC authorized service centers. Parts used for replacement are warranted only for the remainder of this Warranty Period. All products and parts thereof may be brought to a JVC authorized service center on a carry-in basis. Televisions with a screen size of 25 inches and larger may be covered on an in-home basis where such service is available.

WHAT YOU MUST DO FOR WARRANTY SERVICE:
To determine if in-home service is available in your area, either contact the selling dealer (retailer) or call 1-800-537-5722 to locate the nearest JVC authorized service center. Service locations can also be obtained from our website http://www.jvcservice.com. In-home service, if available, will require clear access to the Television by the service representatives. If in-home service is not available, carry in service will be provided.

If service is not locally available, box the product carefully, preferably in its original carton,and ship,insured,with a copy of your bill of sale plus a letter of explanation of the problem to the nearest JVC Factory Service Center, the name and location which will be given to you by the toll free number.

If you have any questions concerning your JVCProduct,please contact our Customer Relations Department.

WHAT IS NOT COVERED:
This limited warranty provided by JVC does not cover:
1) Products which have been subject to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, or if repaired or serviced by anyone other than a service facility authorized by JVC to render such service, or if affixed to any attachment not provided with the products, or if the model or serial number has been altered, tampered with, defaced or removed;
2) Initial installation, installation and removal from "built-in" entertainment centers and other mounting systems;
3) Operational adjustments covered in the Owner's Manual,normal maintenance, video and audio head cleaning;
4) Damage that occurs in shipment,due to an act of God,and cosmetic damage;
5) Signal reception problems and failures due to line power surge;
6) Video Pick-up Tubes/CCD Image Sensor, Cartridge, Stylus (Needle) are covered for 90 days from the date of purchase;
7) Accessories;
8) Batteries (except that Rechargeable Batteries are covered for 90 days from date of purchase.)

There are no express warranties except as listed above.

THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILTY, IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN.

JVC SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE,OR ANY OTHER DAMAGES,WHETHER DIRECT, INCIDENTAL OR CONSEQUENTIAL (INCLUDING,WITHOUT LIMITATION, DAMAGE TO TAPES,RECORDS OR DISCS) RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, ALL EXPRESS AND IMPLIED WARRANTIES,INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE, ARE LIMITED TO THE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion of incidental or consequential damages or limitations on how long the warranty lasts, so these exclusions or limitations may not apply to you.This warranty gives you specific legal rights and you may also have other rights which vary state to state.

JVCCOMPANY OF AMERICA
DIVISION OF JVC AMERICAS CORP.
1700 Valley Road
Wayne, New Jersey 07470
http://www.jvcservice.com

REFURBISHED PRODUCTS CARRY A SEPARATE WARRANTY. THIS WARRANTY DOES NOT APPLY FOR DETAILS OF REFURBISHED PRODUCT WARRANTY. PLEASE REFER TO THE REFURBISHED PRODUCT WARRANTY INFORMATION PACKAGED WITH EACH REFURBISHED PRODUCT.

For customer use:
Enter below the Model No. and Serial No. which is located either on the rear, bottom or side of the cabinet.
Retain this information for future reference.

Model No.: _____ **Serial No.:** _____
Purchase Date: _____ **Name Of Dealer:** _____

Authorized Service Centers

QUALITY JVC SERVICE

HOW TO LOCATE YOUR JVC SERVICE CENTER

TOLL FREE: 1 (800) 537-5722
http://www.jvcservice.com

Dear Customer;
In order to receive the most satisfaction from your purchase, read the instruction booklet before operating the unit. In the event that repair is necessary, or for the address nearest your location, please refer to the factory service center list below or within the Continental United States, call 1-800-537-5722 for your authorized servicer. Remember to retain your Bill of Sale for Warranty Service.

— JVC

JVC SERVICE & ENGINEERING COMPANY OF AMERICA
DIVISION OF JVC AMERICAS CORP.

FACTORY SERVICE CENTER LOCATIONS

Dear customer;

In order to receive the most satisfaction from your purchase, read this guide before operating the unit, and before calling for service make sure you check the Troubleshooting pages at the end of this book. In the event that repair is necessary, or for the address nearest you, please refer to the factory service center list below, or within the continental United States, call the toll free number above for an authorized service center. Remember to retain your bill of sale for warranty service.

10 New Maple Avenue
Pine Brook, NJ 07058-9641
(973) 396-1000

1500 Lakes Parkway
Lawrenceville, GA 30243-5857
(770) 339-2582

705 Enterprise Street
Aurora, IL 60504-8149
(630) 851-7855

5665 Corporate Avenue
Cypress, CA 90630-0024
(714) 229-8011

2969 Mapunapuna Place
Honolulu, HI 96819-2040
(808) 833-5828

10700 Hammerly Suite 110
Houston, TX 77043
(713) 935-9331

13 Cummings Park
Woburn, MA 01801
(781) 376-9100

8192 State Road 84
Davie, FL 33324
(954) 472-1960

890 Dubuque Avenue
South San Francisco, CA 94080-1804
(650) 871-2666

Sophisticated electronic products may require occasional service. Just as quality is a keyword in the engineering and production of the wide array of JVC products, service is key to maintaining the high level of performance for which JVC is world famous. The JVC service and engineering organization stands behind our products.

NATIONAL HEADQUARTERS
JVC SERVICE & ENGINEERING COMPANY OF AMERICA
DIVISION OF JVC AMERICAS CORP.
1700 Valley Road
Wayne, New Jersey 07470

IF YOU SHIP THE PRODUCT

Pack your JVC unit in the original carton or one of equivalent size and strength. Enclose, with the unit, a letter stating the problem or symptom that exists and also a copy of the receipt or bill of sale you received when you purchased your JVC unit. Print your home return address on the outside and inside of the carton, Send to the appropriate JVC Factory Service Center as listed above.

Don't service it yourself

CAUTION

To prevent electrical shock, do not open the cabinet. No user serviceable parts inside. Refer to qualified service personnel.

ACCESSORIES

To purchase accessories for your JVC product, you may contact your local JVC Dealer. Or from the 48 Continental United States call toll free : 1 (800) 882-2345

Notes

Specifications

MODEL	AV-27F502
Reception Format	NTSC, BTSC System (Multi-Channel Sound)
Reception Range	VHF 2 to 13, UHF 14 to 69 Sub Mid, Mid, Super, Hyper and Ultra bands (181 channel frequency synthesizer system)
Power Consumption	140W / 2.0A
Power Source	AC 120V, 60Hz
Screen Size	27 inch / 68 cm measured diagonally
Speakers	2" x 4 3/4" / 5 x 12 cm oval x 2
Audio Output	5W + 5W
Antenna Terminal	75 ohms (VHF/UHF) (F-type connector)
External Input Jacks	Video: 1 Vp-p, 75 ohms Audio: 500mVrms (-4dBs) high impedance
S-Video Input Jacks	Y: 1Vp-p positive, 75 ohms (negative sync provided) C: 0.286 Vp-p (burst signal), 75 ohms
Component Input Jacks	Y: 1Vp-p positive, 75 ohms (negative sync provided) PB/PR: 0.7 Vp-p, 75 ohms
Audio Output Jacks (VAR/FIX)	VAR: More than 0 to 1550 mVrms (+6 dBs), FIX: 500mVrms (-4dBs) Low impedance (400 Hz when modulated 100%)
AV Compu Link EX Jack	3.5 mm mini jack x 1
Dimensions WxHxD (inch/cm)	29 7/8" x 23 3/8" x 19 3/4" / 75.8 x 59.3 x 50.0
Weight (lbs / kg)	101.2 (lbs) / 46 (kg.)
Accessories	Remote control unit / AA batteries x 2

Specifications subject to change without notice.

JVC COMPANY OF AMERICA
Division of JVC Americas Corp.
1700 Valley Road
Wayne, New Jersey, 07470

JVC CANADA, INC.
21 Finchdene Square
Scarborough, Ontario
Canada, M1X 1A7

LCT0821-001A-A
0800-TN-JII-JIM

Other ManualsLib Projects

www.manualslib.com

www.manualslib.de

www.manualslib.es

www.manualslib.fr

www.manualslib.nl

www.manualslib.mx

www.manualslib.tech 30+ Languages